🏡 Tenant Success Tip: Replace Your Keypad Door Lock Battery

If your keypad door lock starts responding slowly, beeping, or has trouble unlocking, the battery may need to be replaced.

How to Replace the Battery:
✅ Remove the interior cover of the lock by removing the screw.
✅ Disconnect and remove the old battery.
✅ Connect a new battery and place it back inside the compartment.
✅ Replace the cover.

Why It Matters:
A dead battery can leave you locked out or unable to use the keypad. Replacing the battery before it dies completely helps ensure reliable access to your home.

Watch the video on how to replace your keypad door lock battery:
https://heartlandapartmentsinrexburg.com/tenant-information/

💡 **Bonus Tip:** Replace the battery as soon as you receive a low-battery warning rather than waiting for it to die completely.

🏠 **Future Homeowner Skill:** Regularly checking and replacing batteries in electronic devices is a simple maintenance habit that can prevent inconvenient and costly problems.